

STEP 1. Clean surface thoroughly with Rapid Tac and a kitchen paper towel. DO NOT USE OTHER CLEANERS OR SOLVENTS. (We do recommend Rapid Prep as a pre-cleaner for surfaces that may have been exposed to wax, silicone, or other suspected contaminants)



STEP 2. Spray surface again with Rapid Tac, peel backing off decal and place on wet surface.



STEP 3. Position decal. Use squeegee to remove fluid, using a good deal of pressure and working from the center out to the edges in all directions.



STEP 4. Wait 2-3 minutes. Saturate paper cover tape, if any, with Rapid Tac, then remove paper tape. Wipe surface with paper towel.

